

PAIRING YOUR SUB WITH THE CORE

Thank you for purchasing Mass Fidelity's Wireless Subwoofer for the Core system. Follow these simple instructions to immediately start using your Sub.

1. Connect the power supply cable to the Sub's input jack and plug the power adapter into a wall outlet.
2. Pair the Sub with a Core speaker, so they can be remembered as a pair on the network:

On your Core speaker: Press and hold the POWER and VOLUME "+" keys for 5 seconds.

The top LED will flash green, once, confirming pairing with your Sub.

Your Core speaker will now always remember the Sub it is paired with, even after powering off.

3. To unpair the Sub from your Core speaker, press and hold the POWER and VOLUME "-" keys for 5 seconds.

WIRED CONNECTION

The Core Sub can also accept wired a 3.5 mm wired signal. When the Sub detects a wired signal it will automatically switch off all wireless functionalities. Once the Sub is wired, its LED indicator will turn to white (line-in).

For further sound tuning and detailed information see the complete instruction manual available on our website:

www.massfidelity.com/support

